

Emblem Application on Clay Roof Top (A)

***Prepare the surface by cleaning to remove contaminants.**

1. Remove mold and Mildew, and efflorescence (a powdery white deposit) found on many concrete and clay surface) with a simple solution of Jomax Mold and mildew cleaner - [A1 (Annexed) Zinsser Jomax; virus and mold killer]

2. Etch the surface with Rust oleum 108 cleaning and etching - [A2 (Annexed) Rusto- Oleum; Concrete Saver 108 Clean and Etch Solution]

3. Remove existing coating if any and patch all holes and cracks especially those showing signs of active leaks, with watertite hydraulic cement [-A3 (Annexed) Zinsser Watertite; Hydraulic Cement]

4. Apply SX0 Primewell

5. Apply base color PL1

6. Apply Red cross design pattern using PL1 Red

7. Broadcast spherical glass beads

8. Apply protective top coat PL1



Emblem Application over Good Applied Membrane Roll(B)

1. Apply Solvent free epoxy primer 4750
2. Apply two coats of 4250
3. Apply base color PL1
4. Apply Red cross design pattern using PL1 Red PL1]
5. Broadcast spherical glass beads
6. Apply protective top coat PL1

Emblem Application on Concrete Surface (C)

1. Repair concrete if needed with SX2 Fillwell
2. Apply SX0 Primewell
3. Apply base color PL1
4. Apply Red cross design pattern using PL1 Red
5. Broadcast spherical glass beads
6. Apply protective top coat PL1 transparent



Emblem Application on Metal Surface (D)

1. In order to obtain best performance, abrasive blast cleaning is recommended. Abrasive blasting/ abrasive sweep blasting: Before blasting any deposits of grease or oil must be removed from the steel surface with suitable detergent followed by high pressure fresh water cleaning. Clean damaged areas thoroughly by power tool cleaning to minimum St 3 or by abrasive blasting to minimum Sa 2, preferably Sa 2 ½. As an alternative, water jetting to minimum Wa 2 (ISO 8501-4:2006)

2. Apply SX-47 Stoprust
3. Apply base color PL1
4. Apply Red cross design pattern using PL1 Red
5. Broadcast spherical glass beads
6. Apply protective top coat PL1 transparent

Emblem Application on Fabric (E)

1. Apply Anti-carbonation primer
2. Apply Acryplus base coat
3. Apply Acryplus coloured coat red
4. Apply PL1 N top coat transparent

